











SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULECOD. **55.0743.00**REV. **00** DEL. **03/07/2021** TEC-LOG **G.D.**Descrizione **Audi A1(GB)****Fig. 1**

-  Togliere la copertura.
-  Remove the cover.
-  Retirez le couverture.
-  Retire la cobertura.
-  Entfernen Sie die Abdeckung.

**Fig. 2**

-  Tagliare lo scarico.
-  Cut the muffler.
-  Couper le silencieux.
-  Corta el silenciador.
-  Schneiden Sie den Schalldämpfer.

**Fig. 3**











-  Installare il tubo centrale.
-  Install the center tube.
-  Installer le tube intermédiaire.
-  Instalar el tramo intermedio.
-  Installieren Sie das Mittelrohr.



Fig. 4

-  Non è più possibile rimontare la copertura.
-  It is no longer possible to refit the cover.
-  Il n'est plus possible de remonter le couvercle.
-  Ya no es posible volver a colocar la cobertura.
-  Es ist nicht mehr möglich, die Abdeckung wieder anzubringen.

